QUICK START GUIDE



A 5G RedCap portable hotspot made for enterprise

### **Included In This Box**

- RHINO H1 Hotspot
- Battery
- USB-C cable (USB 2.0)
- Charger



#### **Get Started**

Press and hold the power button for 4 seconds until the device turns ON and vibrates.

### **User Manual**

Download the full user manual for this device at <a href="https://rhinomobility.com/h1/features">https://rhinomobility.com/h1/features</a>

### **Software and Security Updates**

Check for the latest software and security updates at <a href="https://rhinomobility.com/software-releases">https://rhinomobility.com/software-releases</a>

## **Customer Support**

Online: Go to <a href="https://kb.rhinomobility.com/support">https://kb.rhinomobility.com/support</a> Email: <a href="mailto:support@rhinomobility.com">support@rhinomobility.com</a>

3

# Warranty

Your RHINO device is protected by a one (1) year limited liability warranty against manufacturing defects. This does not affect your statutory rights.

Further warranty can be found at <a href="https://kb.rhinomobility.com/support/rhino-warranty">https://kb.rhinomobility.com/support/rhino-warranty</a>



For all device related information, scan the OR code.

### **Manufacturer Information**

Rhino Mobility LLC 8 The Green, Suite A, Dover, Delaware, 19901, USA

> Manufacturer: Rhino Mobility LLC 8 The Green, Suite A, Dover, Delaware 19901, USA © 2025 Rhino Mobility™. All rights reserved. Not intended for consumer use or resale. H1-007-RHN-0A-001