

How to reboot your RHINO device

To restart your RHINO device:

1. Locate, then press and hold the physical power key on your unit for 2-3s
2. A power menu will pop up, select **Reboot**
3. Your RHINO device will now reboot

Any open apps or files that haven't been saved may be lost when rebooting the device. Please ensure steps are taken to avoid data loss when initiating a reboot.