

# Reset network settings

If you're having issues with connectivity, including Wi-Fi, cellular (mobile data) or Bluetooth, you may opt to reset your network settings as an advanced step in troubleshooting the issue. To reset:

1. Open **Settings**
  1. Either swipe up from the home screen to display the app drawer, and select settings, or
  2. Swipe down from the notification area and tap the settings icon present in the notification panel.
2. Tap **System**
3. Tap **Reset options** (under Advanced)
4. Tap **Reset Wi-Fi, mobile & Bluetooth**
5. Tap **RESET SETTINGS**
6. Tap **RESET SETTINGS** again
7. The RHINO device will begin the irreversible process of resetting all network settings. Be prepared to re-input configurations and saved networks again.