



# RHINO T85

A 5G-powered 8" tablet to elevate your enterprise.

## Included In This Box

- RHINO T85
- USB-C to USB-C cable (USB 2.0)
- Charger block
- Quick start guide
- SIM pin



## Get Started

Press and hold the power button for 4 seconds until the device turns on and vibrates.

This device may be pre-provisioned by your organization, so the Android setup flow you are used to may be interrupted by the Android zero-touch management prompt.

## User Manual

Download the full user manual for this device at [rhinomobility.com](https://rhinomobility.com)

## Software and Security Updates

Check for the latest software and security updates at [rhinomobility.com/software-releases](https://rhinomobility.com/software-releases)

## Customer Support

Online: Go to [kb.rhinomobility.com/support](https://kb.rhinomobility.com/support)  
Email: [support@rhinomobility.com](mailto:support@rhinomobility.com)

## Warranty

Your RHINO device is protected by a one (1) year limited liability warranty against manufacturing defects. This does not affect your statutory rights.

Further warranty can be found at [kb.rhinomobility.com/support/rhino-warranty](https://kb.rhinomobility.com/support/rhino-warranty)

## Documents

View all documents for this device at [rhinomobility.com/t85/specifications](https://rhinomobility.com/t85/specifications)



## CE Statement


1. The adapter shall be installed near the equipment and shall be easily accessible.
2. Do not use the device in the environment at too high or too low temperature, never expose the device under strong sunshine or too wet environment. The operating temperature for the product is 0°C to 40°C (35°C only while charging).
3. **Caution.** Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
4. The SAR limit of Europe is 2.0 W/kg. This device was tested for typical body-worn operations with the 0mm distance from the body and it complies with RF exposure requirements.

Body: 1.688 W/kg


## 5. RF frequency and power

WWAN		
Frequency Band	Maximum output power(dBm)	
WCDMA Band I	24.50	
WCDMA Band VIII	25.50	
LTE B1	24.50	
LTE B3	25.00	
LTE B7	23.50	
LTE B8	24.50	
LTE B20	24.50	
LTE B28	24.50	
LTE B38	24.00	
LTE B41	27.00	
NR n7	25.00	
NR n28	25.00	
NR n41	27.50	
NR n77	28.00	
NR n78	27.50	
WLAN		
Standard	Frequency	EIRP Power(dBm)
WIFI 2.4G	2.4~2.4835GHz	18.38
	5.15~5.25GHz	17.31
WIFI 5G	5.725~5.825GHz	12.70
BLUETOOTH		
Bluetooth Version	EIRP Power(dBm)	
EDR	9.49	
LE	9.16	
NFC		
Frequency	13.56MHz	-17.25 dBμA/m at 10m

6. The Wi-Fi function is restricted to indoor use only when operating in the 5150 MHz to 5350 MHz frequency range.

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK

7. Prevention of Hearing Loss:



## Manufacturer Information

Rhino Mobility LLC  
8 The Green, Suite A, Dover, Delaware, 19901, USA

## EU Regulatory Conformance

Hereby, Rhino Mobility LLC declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the declaration of conformity, visit [rhinomobility.com](http://rhinomobility.com)

Manufacturer: Rhino Mobility LLC  
8 The Green, Suite A, Dover, Delaware 19901, USA  
© 2026 Rhino Mobility™. All rights reserved.  
Not intended for consumer use or resale.  
T85-007-RHN-0A-001